

TOW2025 - Maintenance Workshops

FS Operations

Alexander Neidhardt (TUM Wettzell)

Experience level: Beginners.

Description: This course describes the general structure of the NASA Field System, including important control files, program locations, handling, and so on. We will take a look into installation and setup. Main part is the use of the FS and the adaption of the PC for the Field System.

Thanks for input from Simon Seidl (TUM Wettzell),
Ed Himwich (NVI), Katherine Pazamickas (PERATON),
Christian Plötz (BKG Wettzell)

Code: FSo1, FSo2

TOW2025 - Maintenance Workshops

FS Operations

Where can I get it from?

What is new?

How to install?

Where can I find what on the FS PC?

How to interact with the FS?

How to interact with the FS from remote?

How to configure the FS?

What does a station has to offer to the FS?

How to command the FS?

How to run a schedule with the FS?

How to test the pointing quality?

Where can I get it from?

FS Linux (FSL)

<https://github.com/nvi-inc/fsl11>



Field System

<https://github.com/nvi-inc/fs>

Table 1. FSL distributions

FS Linux	Release Name	Debian Version	Linux kernel	Year
1		(Slackware)	1.2.<x>	1994
2	bo	1.3.1	2.0.29	1997
3	hamm	2.0	2.0.34	1998
	slink	2.1	2.0.36	1999
4	potato	2.2	2.2.18	2000
5	woody	3.0	2.2.20/2.4.18	2002
6	sarge	3.1	2.4.27	2005
7	etch	4.0	2.6.18	2007
8	lenny	5.0	2.6.26	2009
	squeeze	6.0	2.6.32	
9	wheezy	7.0	3.2.0	2014
	jessie	8.0	3.16.0	
10	stretch	9.0	4.9.0	2020
	buster	10.0	4.19.0	<input type="checkbox"/> FS 10.2 release 1.0.4 (2025 Feb.)
11	bullseye	11.0	5.10.0	2023 <input type="checkbox"/> FSL11 release 1.2.0 (2025-02-13)

64-bit

32-bit

Developer:
 J.F.H. Quick
 D.E. Horsley
 W.E. Himwich

TOW2025 - Maintenance Workshops

FS Operations

Where can I get it from?

What is new?

How to install?

Where can I find what on the FS PC?

How to interact with the FS?

How to interact with the FS from remote?

How to configure the FS?

What does a station has to offer to the FS?

How to command the FS?

How to run a schedule with the FS?

How to test the pointing quality?

What is new?



<https://github.com/nvi-inc/fsl11>

New major features in FS 10.2:

- Support for FSL11.
- Support for the new longer IVS experiment names (session codes).
- The plotlog utility has been expanded to include plotting RDBE and DBBC3 data, and many other improvements.
- DBBC3 support has been improved, including support for personality DDC_E and swapping DBBC3 USB and LSB TPIs.

TOW2025 - Maintenance Workshops

FS Operations

Where can I get it from?

What is new?

How to install?

Where can I find what on the FS PC?

How to interact with the FS?

How to interact with the FS from remote?

How to configure the FS?

What does a station has to offer to the FS?

How to command the FS?

How to run a schedule with the FS?

How to test the pointing quality?

How to install?

FS Linux 11 Installation Guide

J.F.H. Quick, D.E. Horsley, and W.E. Himwich - Version 1.0.0 - April 2023

<https://nvi-inc.github.io/fsl11/>

First stage installation

Debian installation

- . In principal, a standard Debian installation
- . Our suggestion: use PC with hardware RAID instead of SW RAID to get better performance and new on-the-fly harddrive changes
- . Our suggestion: directly create account „oper“ instead of „Desktop user“ (4.8), otherwise fsadapt will create the user account
- . Our suggestion: use standard GNOME desktop env., print server, SSH server, and standard system utilities

Second stage installation

Customization (for FS)

- . FS Linux 11 package selection

```
git config -global http.proxy http://<<<your_proxy>>>
apt-get install git dselect
dselect update
cd /root
git clone https://github.com/nvi-inc/fsl11
cd fsl11
dpkg --set-selections < selections/fsl11_amd64.selections
(or dpkg --set-selections < selections/fsl11_i386.selections)
apt-get dselect-upgrade
apt-get clean
```

How to install?

FS Linux 11 Installation Guide

J.F.H. Quick, D.E. Horsley, and W.E. Himwich - Version 1.0.0 - April 2023

<https://nvi-inc.github.io/fsl11/>

Third stage installation

FS installation

- . Call `./fsadapt` (=> shared mem.) as root

Window 1	Window 2	Window 3	Window 4
▪ <code>gplot</code>	▪ <code>set_perms</code>		▪ <code>netssh</code>
▪ <code>systemd</code>	▪ <code>greeter</code>		▪ <code>netsmtp</code>
▪ <code>rtx</code>	▪ <code>serial</code>		▪ <code>netntp</code>
▪ <code>std..</code>			▪ <code>netipp</code>
▪ <code>fstab</code>			▪ <code>netmdns</code>

- . Set passwords and check groups
- . Install FS

```
cd /usr2
git clone https://github.com/nvi-inc/fs fs-git
cd /usr2/fs-git
git checkout -q tag
make install
BECOME USER „prog“
cd /usr2/fs
make >& /dev/null
make -s
```

Eventually necessary to support GPIB (if previously deselected):
`tar --no-same-owner -xvzf linux-gpib-4.0.3.tar.gz`
`cp ./gpib/linux-gpib-4.0.3/include/gpib_user.h /usr/include/gpib/.`

How to install?

FS Linux 11 Installation Guide

J.F.H. Quick, D.E. Horsley, and W.E. Himwich - Version 1.0.0 - April 2023

<https://nvi-inc.github.io/fsl11/>

Appendix

Tuning

- . Optimise system as described in manual
- . Individual software for local use:
nvidia, autoshell, automake, snmp, libmodbus, ...
- . Special suggestions for security/safety:
 - . Screensaver policy (for a machine control system deactivated);
Settings=>Privacy=>Screen Lock; Settings=>Power=>Power Saving;
edit /etc/systemd/sleep.conf and add:
`AllowSuspend=no
AllowHibernation=no
AllowSuspendThenHibernate=no
AllowHybridSleep=no`
 - . Disable „root“ login via SSH and force key use in /etc/ssh/sshd_config:
`PermitRootLogin no
PubkeyAuthentication yes
PasswordAuthentikation no`
 - . Set „xhost +“ in .bashrc of user „oper“ (or restrict it to „prog“ and „root“)

How to install?

FS Linux 11 Installation Guide


J.F.H. Quick, D.E. Horsley, and W.E. Himwich – Version 1.0.0 - April 2023

<https://nvi-inc.github.io/fsl11/>

Appendix cont.

Tuning

- . Special suggestions for security/safety (cont):
 - . Use FS PC as dual-homed host (with filter tables)



- . Always use firewall „ufw“ and define rules, e.g.

```
ufw allow from 192.168.4.25 to any port 10162
```

```
...
```

```
ufw enable
```

How to install?

FS Linux 11 Installation Guide

J.F.H. Quick, D.E. Horsley, and W.E. Himwich – Version 1.0.0 - April 2023

<https://nvi-inc.github.io/fsl11/>

Appendix cont.

Tuning

- . Special suggestions for customization:
 - . Create shortcuts Ctrl – Shift – [2-7] for the different monit windows and Ctrl – Shift – t for fmset (see later)
 Debian-settings □ Keyboard □ Shortcuts, e.g.
`xterm -e /usr2/fs-git/bin/monit2` □ Shortcut Ctrl – Shift – 2
 - . Define a Desktop icon to start the FS and set window positions, fonts, etc.

```
„/usr/share/application/fs.desktop“
[Desktop Entry]
Version=1.0
Name=Nasa Fieldsystem
Comment=Start Fieldsystem
Exec= /usr2/oper/Desktop/fsWindow.sh %U
Icon= /usr2/oper/Pictures/RTW.PNG
Terminal=true
StartupWMClass=fs
Type=Application
Categories=categroy of the application
MimeType=Type of application it should open
```

```
„/usr2/oper/Desktop/fsWindow.sh“
```

```
#!/bin/bash
xterm -e fs &
sleep 1
```

```
„/usr2/oper/.Xresources“, e.g.
```

```
! oprin
oprin.title:
oprin*geometry:
oprin*scrollBar:
oprin*saveLines:
oprin*VT100.Translations: #override\
```

Operator Input
 95x5+0+1100
 true
 100

width in font size
 height in font size
 X-pos in pixel
 Y-pos in pixel

How to install?

FS Linux 11 Installation Guide

J.F.H. Quick, D.E. Horsley, and W.E. Himwich - Version 1.0.0 - April 2023

<https://nvi-inc.github.io/fsl11/>

Or update older versions

Update < 10 10.1 10.2 11

<https://nvi-inc.github.io/fs/releases/10.2/10.2.html>

FS 10.2 Update Notes

Version 1.0.4 - February 2025

But better (my personal opinion):

- Install a completely new computer with 64-bit Debian
- Install FSL11 or greater for 64-bit and latest FS version
- Copy your station code
- Go manually through control files and change them accordingly
- Go manually through your code and change it manually to int,
where required (so that you can also validate address operations etc.)

TOW2025 - Maintenance Workshops

FS Operations

Where can I get it from?

What is new?

How to install?

Where can I find what on the FS PC?

How to interact with the FS?

How to interact with the FS from remote?

How to configure the FS?


What does a station has to offer to the FS?

How to command the FS?

How to run a schedule with the FS?

How to test the pointing quality?

Where can I find what on the FS PC?



Where can I find what on the FS PC?

The directory structure


/usr2		
└ ./oper	Home of user „oper“	Home directories
└ ./prog	Home of user „prog“	
└ ./fs	Sym. link to ./fs-git	
└ ./fs-git	Code of the FS release	Field System installation and configuration
└ ./control	Configuration files	
└ ./st	Sym. link to ./st-git	
└ ./st-git	Code of the station spec. code	
└ ./log	Log files for each session	
└ ./proc	Procedure files for each session	Operations
└ ./sched	Schedule files for each session	
└ ./tle_files	TLE files for satellite orbits	

Where can I find what on the FS PC?

The directory structure

	/usr2		
See prev. slides	./oper	Home of user „oper“	Home directories
	./prog	Home of user „prog“	
	./fs	Sym. link to ./fs-git	
	./fs-git	Code of the FS release	Field System installation and configuration
See Seminar FS Station Code	./control	Configuration files	
	./st	Sym. link to ./st-git	
	./st-git	Code of the station spec. code	
	./log	Log files for each session	
	./proc	Procedure files for each session	Operations
	./sched	Schedule files for each session	
	./tle_files	TLE files for satellite orbits	

Where can I find what on the FS PC?



TOW2025 - Maintenance Workshops

FS Operations

Where can I get it from?

What is new?

How to install?

Where can I find what on the FS PC?

How to interact with the FS?

How to interact with the FS from remote?

How to configure the FS?

What does a station has to offer to the FS?

How to command the FS?


How to run a schedule with the FS?

How to test the pointing quality?

How to interact with the FS?

Start and stop the FS

Start: Enter fs in an xterm or in the login shell



Stop: Enter terminate in the Operator Input and confirm with „Y“es

How to interact with the FS?

FS Windows „System Status Monitor“ (monit2)

```
WETTZELL          2023.108.21:46:42  UT           TEMP      7.2C 0133+476   SLEWING
MODE RATE          21:49:42  NEXT          HUMID    99.70% RA  01h36m58.6s
SCHED=none        LOG=station  PRES   951.5mb DEC 47d51m   (2000)
TSYS: IFA IFB IFC IFD CABLE 0.006382s AZ  347.7  EL   8.4
          43   75  102 -35
NO CHECK: rx
```

How to interact with the FS?

FS Windows „System Temperatures“ (monit3)

Tsys	42.6 (IFA)	74.7 (IFB)	
	101.5 (IFC)	-35.7 (IFD)	
BBC	Freq	Ts-U	Ts-L
01	132.99	57.3	55.6
02	172.99	64.9	
03	272.99	48.3	
04	432.99	48.4	
05	652.99	57.0	
06	772.99	47.8	
07	832.99	47.9	
08	852.99	53.3	49.8
09	205.99	74.5	
10	225.99	81.2	
11	245.99	97.5	
12	275.99	108.9	
13	325.99	85.8	
14	345.99	81.7	
15			
16			

How to interact with the FS?

FS Windows „LBA Data Acquisition System Monitor“ (monit4)

```
DAS MONITOR

IF PROCESSOR 1: | IF PROCESSOR 2:
IFFP1: WAITING for SETUP | IFFP2: WAITING for SETUP
-----+-----+
IF : | IF :
LEVL: >-----^-----< | LEVL: >-----^-----<
OFFS: >-----^-----< | OFFS: >-----^-----<

BS : | BS :
U-TH: >-----^-----< | U-TH: >-----^-----<
L-TH: >-----^-----< | L-TH: >-----^-----<

FT : | FT :
U-TH: >-----^-----< | U-TH: >-----^-----<
L-TH: >-----^-----< | L-TH: >-----^-----<

-----+-----+
CLKS: | BLANK: | CLKS: | BLANK:
5 MHz: | 1 PPS: | 5 MHz: | 1 PPS:
VOLTS: | TEMPS: | VOLTS: | TEMPS:
```

How to interact with the FS?

FS Windows
„Mark5 Remaining Capacity“
(monit5)

Mark 5 Remaining Capacity					
VSN	Time	GB	z	Check	UT
> A WSRT-049	15h14m	1755.239	87.8	23:52:13	
B				23:52:13	

How to interact with the FS?

FS Windows „RDBE Monitoring“ (monit 6)

RDBE	DOT	EPOCH	DOT2GPS	DOT2PPS	IF	RMS	IFO	TSys	IF1	TSys	Tone	Amp	Phase
a	2023.108.22:25:01	46	-71.121	-0.020	1	2.5	Avg	\$\$\$\$\$	Avg	\$\$\$\$\$	1a0030	0.1	-152.9
b	2023.108.22:25:01	46	-71.125	-0.020	1	19.9	Avg	34.6	Avg	41.8	1b0030	88.0	-161.4
c	2023.108.22:25:01	46	-71.121	-0.020	1	19.1	Avg	29.2	Avg	32.6	1c0030	64.7	-10.0
d	2023.108.22:25:01	46	-71.125	-0.020	1	20.1	Avg	43.1	Avg	39.5	1d0030	25.0	-102.7

How to interact with the FS?

FS Windows „System Temperatures of DBBC3“ (monit 7)

System Tempera...			
IF A L0	8080.0	USB Rec	
Delay	16	Tsys	52.2
Time	2023.109.21:25:11		
Epoch	-- DBBC3-FS	0	
BBC	RF	Ts-U	Ts-L
001	8319.5	64.1	72.6
002	8383.5	73.7	64.9
003	8447.5	69.7	77.4
004	8511.5	55.7	55.8
005	8639.5	79.1	58.5
006	8703.5	75.2	98.8
007	8767.5	69.5	62.0
008	8831.5	82.9	78.3

How to interact with the FS?

FS Windows „fmset“

```
fmset - VLBA & Mark IV formatter/S2-DAS/S2-RT/Mark5B/FiLal0G time set

FiLal0G      22:03:47.0 UT 18 Apr (Day 108) 2023
Field System  22:03:47.1 UT 18 Apr (Day 108) 2023 model: computer
Computer     22:03:47.1 GMT 18 Apr (Day 108) 2023 NTP: unknown

Use '+'      to increment FiLal0G time by one second.
'-'      to decrement FiLal0G time by one second.
'='      to be prompted for a new FiLal0G time.
'.'      to set FiLal0G time to Field System time.
's'/'S'  to sync FiLal0G (VERY rarely needed)
<esc>    to quit: DON'T LEAVE FMSET RUNNING FOR LONG.
```

How to interact with the FS?

Individual FS Station Windows „Antenna Monitoring“

Antenna Monitoring		
RTW ([2023] 108.22:02:52:714 (Offset: 0 msec))		
Azimuth	Source: Stop	Elevation
59.9789	Actual Pos.	25.0383
	Pos. Graph	
59.9789	Commanded Pos.	25.0383
350.4344	NASA FS Pos.	7.8963
0.0000	Com. Pos. Offset	0.0000
STOP	Status	STOP
Status messages		
[Azimuth] Stop Stow pin retracted	[General] ACU type: RTW Reduced internal limits che Green mode inactive	[Elevation] Stop Stow pin retracted
Error messages		

TOW2025 - Maintenance Workshops

FS Operations

Where can I get it from?

What is new?

How to install?

Where can I find what on the FS PC?

How to interact with the FS?

How to interact with the FS from remote?

How to configure the FS?

What does a station has to offer to the FS?

How to command the FS?

How to run a schedule with the FS?

How to test the pointing quality?


How to manually interact with the FS from remote?

Standard remote control:

`/usr2/fs/bin/fsclient` via SSH-connection and X-forwarding

`fsclient`

Start the client windows




How to manually interact with the FS from remote?

Standard remote control:

`/usr2/fs/bin/fsclient` via SSH-connection and X-forwarding

`client=` commands in fsclient-oprin (not in „oprin“-call in a shell)



Control your FS from MS Windows:

- Install X-Window-Server, e.g. Xming or VcXsrv Windows X Server
- Connect to the FS PC using SSH with X-forwarding
- Start „fsclient“

How to manually interact with the FS from remote?

Standard remote control:

/usr2/fs/bin/fsclient via SSH-connection and X-forwarding

client= commands in fsclient-oprin

/usr2/control/clpgm.ctl

```
* Put programs here that can be accessed with
* "client=" FS client.
* flags accepted are:
*      a start attached to the calling client, ie exit with client
*      d start detached, ie will not exit with client
erchk a xterm -name erchk -e erchk
fmset d xterm -name fmset -e fmset
pfmed d xterm -name pfmed -e pfmed
monitl a xterm -name monitl -e monitl
monit2 a xterm -name monit2 -e monit2
monit3 a xterm -name monit3 -e monit3
monit4 a xterm -name monit4 -e monit4
monit5 a xterm -name monit5 -e monit5
monit6 a xterm -name monit6 -e monit6
monit7 a xterm -name monit7 -e monit7
scnch a xterm -name scnch -e 'fsclient -n -w -s | grep /!\\*scan_check..'
xterm d xterm
monan a xterm -name monan -e monan
mona d popen 'cd /tmp;rdbe30_mon.py -h 239.0.2.10 -p 20021 -H rdbea 2>&1' -n rdbemona
monb d popen 'cd /tmp;rdbe30_mon.py -h 239.0.2.20 -p 20022 -H rdbeb 2>&1' -n rdbemonb
monc d popen 'cd /tmp;rdbe30_mon.py -h 239.0.2.30 -p 20023 -H rdbec 2>&1' -n rdbemonc
mond d popen 'cd /tmp;rdbe30_mon.py -h 239.0.2.40 -p 20024 -H rdbed 2>&1' -n rdbemond
```

TOW2025 - Maintenance Workshops

FS Operations

Where can I get it from?

What is new?

How to install?

Where can I find what on the FS PC?

How to interact with the FS?

How to interact with the FS from remote?

How to configure the FS?

What does a station has to offer to the FS?

How to command the FS?

How to run a schedule with the FS?

How to test the pointing quality?

How to configure the FS?

Control files /usr2/control

antenna.ctl	Antenna control file (diameter, speed, ...)
dev.ctl	Devices (GPIB, Mark III, antcn , ...)
time.ctl	FS Timing (Computer NTP , Recorder, ...)
skedf.ctl	Drudg (Printer, ...)
location.ctl	Location of the site (Long, Lat, Height, ...)
flagr.ctl	Antenna on/off-source check interval

rxg_files/s.rxg	Receiver parameter S-band
rxg_files/x.rxg	Receiver parameter X-band
equip.ctl	Equipment control file (BBC, recorder, ...)
rdbE.ctl	RDBE control file
fila10g_cfg.ctl	FILA10g control file
dbbad.ctl	Control file for first DBBC (IP , Port , ...)
dbba2.ctl	Control file for second DBBC (IP , Port , ...)

mk5ad.ctl	Mark5 control file (IP , Port , ...)
mk6ca.ctl	Mark6 control file (IP , Port , ...)

See
Seminar
FS Station
Code

{

- sterr.ctl
- stcmd.ctl
- stpgm.ctl
- ...

Station error numbers and corresponding text
Station specific commands
Start of station specific programs

How to configure the FS?

Control files /usr2/control

antenna.ctl

Antenna control file (diameter, speed, ...)

dev.ctl

Devices (GPIB, Mark III, [antcn](#), ...)

time.ctl

FS Timing ([Computer NTP](#), Recorder, ...)

skedf.ctl

Drudg (Printer, ...)

location.ctl

Location of the site (Long, Lat, Height, ...)

flagr.ctl

Antenna on/off-source check interval

rxg_files/s.rxg

Receiver parameter S-band

rxg_files/x.rxg

Receiver parameter X-band

equip.ctl

Equipment control file (BBC, recorder, ...)

rdbe.ctl

RDBE control file

fila10g_cfg.ctl

FILA10g control file

dbbad.ctl

Control file for first DBBC ([IP](#), [Port](#), ...)

dbba2.ctl

Control file for second DBBC ([IP](#), [Port](#), ...)

mk5ad.ctl

Mark5 control file ([IP](#), [Port](#), ...)

mk6ca.ctl

Mark6 control file ([IP](#), [Port](#), ...)

See

Seminar
FS Station
Code

sterr.ctl

Station error numbers and corresponding text

stcmd.ctl

Station specific commands

stpgm.ctl

Start of station specific programs

...

How to configure the FS?

Control files /usr2/control/antenna.ctl

```
***** Antenna Control File *****  
*  
    13.2      Antenna Diameter (meters)  
  720.      HA/AZ/X Slew Speed (deg/min)  
  360.      DEC/EL/Y Slew Speed (deg/min)  
 -90.0     HA/AZ/X Lower Limit (deg)  
 450.0     HA/AZ/X Upper Limit (deg)  
   0.0      DEC/EL/Y Lower Limit (deg)  
 115.0     DEC/EL/Y Upper Limit (deg)  
 azel      Antenna Axis Type (AZEL,HADC,XYEW,XYNS)
```

How to configure the FS?

Control files /usr2/control/location.ctl

```
***** Location Control File *****
*
WETTZ13S      Station Name
-12.878278    WEST Longitude
49.143415     Latitude
672.5798      Station Elevation (meters)
* Horizon mask
* az1 ell az2 el2 . . .
0 10 360
```

How to configure the FS?

Control files /usr2/control/equip.ctl

```
***** equip.ctl Equipment Control File *****
* Please refer to the Control Files Manual in Volume 1 of the
* Field System Documentation
*
* VLBI equipment
dbbc_pfb/fila10g    type of rack (mk3, vlba, vlbag, mk4, vlba4, mk5, vlba5
*                         k4l, k4lu, k4l/k3, k4lu/k3, k4l/mk4, k4lu/mk4,
*                         k42, k42a, k42b, k42bu, k42c, k42/k3, k42a/k3,
*                         k42bu/k3, k42/mk4, k42a/mk4, k42b/mk4, k42bu/mk4
*                         k42c/mk4, lba, lba4, s2, dbbc_ddc, dbbc_ddc/fila10g,
*                         dbbc_pfb, dbbc_pfb/fila10g, vlbac, cdas, rdbe,
*                         dbbc3_ddc_u, dbbc3_ddc_v, or none)
mk6      type of recorder 1 (mk3, vlba, vlbab, vlbab, vlba4, mk4,
*                         mk4b, s2, k4l, k4l/dms, k42, k42/dms, mk5a, mk5a_bs,
*                         mk5b, mk5b_bs, mk5c, mk5c_bs, flexbuff, mk6, or none)
none     type of recorder 2 (mk3, vlba, vlbab, vlbab, vlba4, vba42, mk4,
*                         mk4b, or none)
none     type of decoder (mk3, dqa, mk4, or none)
*
* Mark III/IV rack parameters
500.10 IF3 LO Frequency
    3    hex mask indicating which IF3 switches are installed, sw N ~ 2^(N-1)
*
* VLBA/4 rack parameters
a/d    VLBA formatter cross-point switch (a/d or dsm)
101    Hardware ID for VLBA rack (assigned by GSFC)
*
* CDP S/X Receiver Parameters
60    Receiver 70K Stage Check Temperature
20    Receiver 20K Stage Check Temperature
* pcal control
none    type of phase cal control (if3 or none)
*mk iv fm firmware version
41    pre-40 versions have no barrel-rolling or data modulation
*
* LBA/4 rack parameters
    1    No of LBA DAS installed (up to MAX_DAS - see "params.h")
    in    160MHz IF input filters (in or out)
    8bit  Digital input setting (8bit internal sampler or 4bit external at ATCA)
* met sensor type
*default choice for metserver is 50001 localhost, cdp or met3 server port, use cdp if you don't have either
cdp    cdp or met3 server port, use cdp if you don't have either
* default mk4 form command synch test value
3    off or 0, 1, ..., 16
*mk4 decoder transmission terminator
return return, $, or %
```

How to configure the FS?

Control files /usr2/control/equip.ctl (cont.)

```
*DBBC DDC version
v105_1  v100, v101, v102, v104, v105, v105e, v105f, ...
*DBBC PFB version
v16_1  v12  v15_1 or later
*DBBC Cores per CoMo, Max of 4 values, range of values 0-4,
* total of values <= 4, one value for each CoMo present in order: A B C D
1 1 1 1
*DBBC IF power conversion factors, one for each module specified above, no trailing comments or extra fields
15000 15000 15000 15000
*VSI-H/Mark5B clock rate (MHz): "nominal" is:
*
*          32 for rack=Mark5 or VLBA5,
*          rack=DBBC DDC, any letter,
*                  v104 or less,
*                  with and without
*                  FiLa10G
*          rack=DBBC DDC, letter ' ',
*                  v105-v106,
*                  with and without
*                  FiLa10G
*          rack=VLBAC
*          64 for rack=DBBC DDC, letters E/F,
*                  v105 or greater,
*                  with and without
*                  FiLa10G
*          rack=CDAS
*          rack=DBBC DDC, letter ' ',
*                  v107 or later,
*                  without FiLa10G
*          128 for rack=DBBC DDC, letter ' ',
*                  v107 or later,
*                  with FiLa10G
*          0 otherwise except rack=none
*          "nominal" is not allowed for rack=none
* a clock rate value of "none" will suppress clock set command in FMSET
* nominal    one of: none, nominal, 2, 4, 8, 16, 32, 64, 128
*FiLa10G input select, one of: vsil, vsi2, vsil-2, vsil-2-3-4, gps, tvg
vsil
```

How to configure the FS?

Control files **/usr2/control/mk6ca.ctl**

```
*mk6ca.ctl example file
* line 1: host(IP address or name) port(2620) time-out(centiseconds)
* using an IP address avoids name server and potential network problems
* example: remote host uses a long time-out
*   mark5-04.haystack.mit.edu
*   192.52.61.178 2620 500
* example: local host uses a short time-out
127.0.0.1 14241 500
```

How to configure the FS?

Control files /usr2/control/stpgm.ctl

```
* Put site-specific programs here that should
* be started by the Field System.
* antcn should not be here.
erchk x xterm -name erchk -e erchk &
moni2 x xterm -name monit2 -e monit2 &
scnch x xterm -name scnch -e 'fsclient -n -w -s | grep /!\*scan_check..' &
wx2fs n wx2fs > /dev/null 2> /dev/null &
stqkr n stqkr /usr2/st/control/stqkr.conf &
cable2fs n cable2fs /usr2/st/control/cable2fs.conf &
patch_mark6.sh x /usr2/st/bin/patch_mark6.sh init:192.168.1.1:14 &
```

FS
programs

Station
programs

Remember
„/usr2/oper/.Xresources“
to set positions and fonts etc.

TOW2025 - Maintenance Workshops

FS Operations

Where can I get it from?

What is new?

How to install?

Where can I find what on the FS PC?

How to interact with the FS?

How to interact with the FS from remote?

How to configure the FS?

What does a station has to offer to the FS?

How to command the FS?

How to run a schedule with the FS?

How to test the pointing quality?

What does a station has to offer to the FS?

Station-specific programs

See Seminar „FS Station Code“

Antenna Control („antcn“)

Activated in dev.ctl

Station specific commands („stqkr“)

Activated in stpgm.ctl

Station specific programs
to fill shared memory
 („wx2fs“, „cable2fs“)

Activated in stpgm.ctl

Station specific programs
do local tasks
(e.g. local data monitoring)

TOW2025 - Maintenance Workshops

FS Operations

Where can I get it from?

What is new?

How to install?

Where can I find what on the FS PC?

How to interact with the FS?

How to interact with the FS from remote?

How to configure the FS?

What does a station has to offer to the FS?


How to command the FS?

How to run a schedule with the FS?


How to test the pointing quality?

How to command the FS?

Operator input („oprin“)



SNAP commands (Standard Notation for Astronomical Procedures)



How to command the FS?


SNAP commands (Standard Notation for Astronomical Procedures)

SNAP in active Session SNAP File

/usr2/sched/<sessionname>.snp
<sessionname> = <session><antennacode>
e.g. r4125wz.snp

SNP-files are sequences of time-tagged SNAP commands

```
" R4999      2021 WETTZELL V Wz
" V WETTZELL AZEL .0000 240.0    2 251.5 831.0 90.0    2   5.0   89.0 20.0 Wz 33
" Wz WETTZELL 4075539.50530 931735.66250 4801629.61560 72247801
" 33 WETTZELL 0 17640
" drudg version 2019Sep23 compiled under FS 9.13.02
" Rack=DBBC_DDC Recorder 1=FlexBuff Recorder 2=none
scan_name=140-1933,r4999,wz,60,60
source=3c418,203837.03,511912.7,2000.0,ccw
setupx
!2021.140.19:33:07
preob
!2021.140.19:33:17
sy=cmd2flexbuff.py net2file=open:/raid/r4999wz/r4999_wz_140-1933,n ;
data_valid=on
midob
!2021.140.19:34:17
data_valid=off
sy=cmd2flexbuff.py net2file = close
postob
scan_name=140-1935,r4999,wz,60,60
source=0552+398,055530.81,394849.2,2000.0,ccw
```




How to command the FS?

SNAP commands (Standard Notation for Astronomical Procedures)

SNAP in active Session Procedure File

/usr2/proc/<sessionname>.prc
<sessionname> = <session><antennacode>
e.g. r4125wz.prc



How to command the FS?

SNAP commands (Standard Notation for Astronomical Procedures)

SNAP in Station Procedure File

/usr2/proc/station.prc

sched_initi

preob

midob

postob

...

Tasks at schedule start

Tasks before scan recording

Tasks while scan recording

Tasks after scan recording

e.g.

```
define midob      2310818300lx
onsource
antenna=status
wx
rx=dewar?
cable
ifa
ifb
ifc
ifd
bbc01
bbc05
bbc09
bbc13
" the shown order of the commands from here to the end of this procedure is
" strongly recommended
"add your station command to measure the gps to fm output clock offset
"gps-fmout=c2
mk5c_mode
!+ls
"mk5=dot?
sy=run setcl adapt &
enddef
```

**Attention: Changes of station.prc require
that the TS is not running.**

Procedures are selections of other SNAP calls

How to command the FS?

SNAP commands (Standard Notation for Astronomical Procedures)

SNAP implementation in station code

„stqkr“

wx Print meteo values
dotmon Print gps-fmout
dotmon2 Print gps-fmout of 2. DBBC2
cable Print cable measurement
rx= Print or set receiver values
...
...

„antcn“

source= Point antenna to new source
onsource Check if antenna points
antenna= Print or set antenna values

See
Seminar
FS Station
Code

How to command the FS?

SNAP commands (Standard Notation for Astronomical Procedures)

SNAP implementation in FS code

"ls /usr2/fs/help" or SNAP-command "help=" in oprin

schedule=	Start new schedule
halt	Interrupt running schedule
cont	Continue schedule
mk5=	Print or set Mark5 values
mk6=	Print or set Mark6 values
sy=	Do a system call
scan_check	Run a scan check on Mark5 or Mark6
log=	Set log file
proc=	Set new procedure file
fivept	Run automated pointing test
onoff	Run antenna calibration test (SEFD)
acquire	Run a pointing test schedule
...	

TOW2025 - Maintenance Workshops

FS Operations

Where can I get it from?

What is new?

How to install?

Where can I find what on the FS PC?

How to interact with the FS?

How to interact with the FS from remote?

How to configure the FS?


What does a station has to offer to the FS?

How to command the FS?


How to run a schedule with the FS?

How to test the pointing quality?


How to run a schedule with the FS?




How to run a schedule with the FS?




How to run a schedule with the FS?



How to run a schedule with the FS?




How to run a schedule with the FS?




How to run a schedule with the FS?


2021.140.19:32:00.00@Log Opened: Mark IV Field System Version 9.13.2
 2021.140.19:32:00.00@release,9.13.2
 2021.140.19:32:00.00@location,WETTZELL,-12.88,49.15,661.2
 2021.140.19:32:00.00@horizon1,0.,10.,360.
 2021.140.19:32:00.00@antenna,20.0,240.0,90.0,-118.0,475.5,5.0,88.5,azel
 2021.140.19:32:00.00@equip,dbbc_ddc/filal0g,flexbuff,none,none,500.10,3,a/d,101,70,25,none,41,1,in,8bit,cdp,3,return,v105_1,v15_1,1,1,1,1
 ,15000,15000,15000,15000,32,vsil
 2021.140.19:32:00.00@time,0.000,1.000,computer
 2021.140.19:32:00.00@flagr,200
 2021.140.19:32:00.00@fsserver,disabled
 S 2021.140.19:32:00.00: R4999 2021 WETTZELL V Wz
 2021.140.19:32:00.00:" Wz WETTZELL AZEL .0000 240.0 2 251.5 831.0 90.0 2 5.0 89.0 20.0 Wz 33
 2021.140.19:32:00.00:" Wz WETTZELL 4075539.50530 931735.66250 4801629.61560 72247801
 2021.140.19:32:00.00:" 33 WETTZELL 0 17640
 2021.140.19:32:00.00:" drudg version 2019Sep23 compiled under FS 9.13.02
 2021.140.19:32:00.00:" Rack=DBBC_DDC Recorder 1=FlexBuff Recorder 2=none
 2021.140.19:32:00.00:exper_initi
 2021.140.19:32:00.00&exper_initi/proc_library
 2021.140.19:32:00.00&exper_initi/sched_initi
 2021.140.19:32:00.00&exper_initi/mk5=dts_id?
 2021.140.19:32:00.00&exper_initi/mk5=os_rev?
 2021.140.19:32:00.00&exper_initi/mk5_status
 2021.140.19:32:00.00&exper_initi/dbbc=version
 2021.140.19:32:00.00&exper_initi/filal0g=version
 2021.140.19:32:00.00&proc_library/" r4999 wettzell wz
 2021.140.19:32:00.00&proc_library/" drudg version 2019sep23 compiled under fs 9.13.02
 2021.140.19:32:00.00&proc_library/"< dbbc_ddc/filal0g rack >< flexbuff recorder 1>
 2021.140.19:32:00.00&sched_initi/azeloff=0d,0d
 2021.140.19:32:00.00&sched_initi/+2s
 2021.140.19:32:00.00&sched_initi/check=all,-rx
 2021.140.19:32:00.00&sched_initi/sy=/usr2/st/bin/errorfilter.sh &
 2021.140.19:32:00.00&sched_initi/sy=/usr2/st/bin/checkflexbuffrecording.sh &
 2021.140.19:32:00.00&sched_initi/jive5ab=version?
 2021.140.19:32:00.00&sched_initi/filal0g_cfg
 2021.140.19:32:00.00&sched_initi/filal0g_mac
 2021.140.19:32:00.00&sched_initi/filal0g_bb
 2021.140.19:32:00.00&sched_initi/filal0g=time
 2021.140.19:32:02.03/jive5ab!/version? 0 : jive5ab : 3.0.0 : 64bit : Release : flexbuff2 : 22-Mar-2020 : 14h16m48s : nossapi : ;
 2021.140.19:32:02.03&filal0g_cfg/"filal0g=reboot
 2021.140.19:32:02.03&filal0g_cfg/"!+2s
 2021.140.19:32:02.03&filal0g_cfg/filal0g=splitmode off
 2021.140.19:32:02.03&filal0g_cfg/filal0g=inputselect vsil
 2021.140.19:32:02.03&filal0g_cfg/filal0g=vs1_inputwidth 32
 2021.140.19:32:02.03&filal0g_cfg/filal0g=vs1_samplerate 32000000 2
 2021.140.19:32:02.03&filal0g_cfg/filal0g=vs1_bitmask 0xffffffff
 2021.140.19:32:02.03&filal0g_cfg/"filal0g=reset
 2021.140.19:32:02.03&filal0g_cfg/"!+ls
 2021.140.19:32:02.03&filal0g_cfg/filal0g=vdif_station wz
 2021.140.19:32:02.03&filal0g_cfg/filal0g=vdif_frame 2 16 8000
 2021.140.19:32:02.03&filal0g_cfg/filal0g=arp off
 2021.140.19:32:02.03&filal0g_cfg/filal0g=tengbcfg eth0 ip=192.168.1.40 gateway=192.168.1.1
 2021.140.19:32:02.03&filal0g_cfg/filal0g=tengbcfg eth0 mac=ba:dc:af:e4:be:f0
 2021.140.19:32:02.03&filal0g_cfg/filal0g=tengbcfg eth0 nm=27
 2021.140.19:32:02.03&filal0g_cfg/filal0g=tengbcfg eth1 ip=192.168.1.41 gateway=192.168.1.1
 2021.140.19:32:02.03&filal0g_cfg/filal0g=tengbcfg eth1 mac=ba:dc:af:e4:be:f1
 2021.140.19:32:02.03&filal0g_cfg/filal0g=tengbcfg eth1 nm=27
 2021.140.19:32:02.03&filal0g_cfg/" connection to flexbuff1 (98)



How to run a schedule with the FS?



How to run a schedule with the FS?



TOW2025 - Maintenance Workshops

FS Operations

Where can I get it from?

What is new?

How to install?

Where can I find what on the FS PC?

How to interact with the FS?

How to interact with the FS from remote?

How to configure the FS?

What does a station has to offer to the FS?

How to command the FS?

How to run a schedule with the FS?

How to test the pointing quality?

How to monitor system quality?

Automated Pointing Model

Also see: E. Himwich, „Automated Pointing Models Using the FS“

Setup:

- „ant cn“ must support ONSOURCE modes
 - see Seminar FS Station Code

Configure „s.rxg“ and „x.rxg“

Customize „point.prc“

Customize „parpo.ctl“

Customize „mdlpo.ctl“ (no changes requ.)

Check „flux.ctl“ (no changes requ.)

(If you have a non-standardized system, e.g. no noise diode or individual detector, check documentation.)

How to monitor system quality?

Automated Pointing Model

Also see: E. Himwich, „Automated Pointing Models Using the FS“

Setup:

„ant cn“ must support ONSOURCE modes
 see Seminar FS Station Code

Configure „s.rxg“ and „x.rxg“

Customize „point.prc“

Customize „parpo.ctl“

Customize „mdlpo.ctl“ (no changes requ.)

Check „flux.ctl“ (no changes requ.)

(If you have a non-standardized system, e.g. no noise diode or individual detector, check documentation.)

„x.rxg“ sample

S/X	VGOS (DBBC)
1. Line (LO) fixed 8080	fixed 7580 7580
2. Line (File date)	2022 04 17
3. Line (Model beamwidth)	frequency 1.0
4. Line (Polarization)	rcp
5. Line (Degrees Per Flux Unit)	0.00126
6. Line (Gain curve)	ELEV POLY 1.0
7. Line (Tcal vs. frequ)	
rcp 8080.0 20.8	rcp 8200.0 6.4
end_tcal_table	rcp 8400.0 6.5
	rcp 8600.0 6.2
	rcp 8800.0 6.2
	end_tcal_table

...

How to monitor system quality?

Automated Pointing Model

Also see: E. Himwich, „Automated Pointing Models Using the FS“

Setup:

„antcn“ must support ONSOURCE modes

- see Seminar FS Station Code

Configure „s.rxg“ and „x.rxg“

Customize „point.prc“

Customize „parpo.ctl“

Customize „mdlpo.ctl“ (no changes requ.)

Check „flux.ctl“ (no changes requ.)

(If you have a non-standardized system, e.g. no noise diode or individual detector, check documentation.)

```
...
define initp          23107122005
"setup
caloff
"sample fivept set-up for azel antenna
" with Mark III/IV rack
"fivept=azel,-2,9,.4,1,i1,120
"sample fivept set-up for azel antenna
" with VLBA/4 rack or DBBC
"...,axis,rep,pts,stepsize,integ_period,dev,wait_on_onsource
fivept=azel,2,9,0.5,5,ia,120
" sample onoff set-up for Mark III/IV
"onoff=2,1,75,3,,120,all
" sample onoff set-up for VLBA/4 or DBBC
"onoff=2,1,75,3,,120,allu,ia,ib,ic
sy=brk onoff &
"...,rep,integ_period,cutoff_elev,dist_offsource,snap_proc,
"wait_on_onsource,devices
onoff=2,1,75,3,,120,formbbc,ia,ib,ic
check=
sy=go aquir &
enddef

...
```

How to monitor system quality?

Automated Pointing Model

Also see: E. Himwich, „Automated Pointing Models Using the FS“

Setup:

„ant cn“ must support ONSOURCE modes

- see Seminar FS Station Code

Configure „s.rxg“ and „x.rxg“

Customize „point.prc“

Customize „parpo.ctl“

Customize „mdlpo.ctl“ (no changes requ.)

Check „flux.ctl“ (no changes requ.)

(If you have a non-standardized system, e.g. no noise diode or individual detector, check documentation.)

1. Line (Telescope)
WETTZELL azel

2. Line (Parameters)
0 0.075 0.115 1.25

3. Line (Model beamwidth)
3

How to monitor system quality?

Automated Pointing Model

log=pointing	Define log file
proc=r41097wz	Set procedure with BBC, IF, ... settings
setupsx	Setup BBC, IF, ... settings
proc=point	Define pointing procedure
cygnusa	Point to source
initp	Init fivept
ifman	Local command to switch AGC off
fivept	Start fivept <input type="checkbox"/> offsets
onoff	Start onoff <input type="checkbox"/> SEFDs

**Process „fivept“
and „onoff“**

How to monitor

Automate

log=pointing
 proc=r41097wz
 setupsx
 proc=point
 cygnusa
 initp
 ifman
 fivept
 onoff

Define log file
 Set procedure with B
 Setup BBC, IF, ... se
 Define pointing proce
 Point to source
 Init fivept
 Local command to sw
 Start fivept offsets
 Start onoff SEFDs

Process „fivept“ and „onoff“

```

2023,107,14;15:48,26;#fivept
2023,107,14;15:48,26#fivpt#source cygnusa 195928.4 +404402 2000.0 2023,107,14;15:48
2023,107,14;15:48,26#fivpt#site WETTZELL -12,8772 49,1450 20.00 xxxx 0 1.00 0.00
2023,107,14;15:48,26#fivpt#fivept azel 2 9 0,50 5 ia 20.8 0.1256 183.5
2023,107,14;15:48,26#fivpt#origin 0.0000 0.0000 0.0016 0.0047 0.0000 0.0000
2023,107,14;15:48,30;calofffp
2023,107,14;15:48,30&calofffp/caloff
2023,107,14;15:48,30&calofffp/sy=go fivpt &
2023,107,14;15:48,30&calofffp/!+ls
2023,107,14;15:48,30&calofffp/sy=go fivpt &
2023,107,14;15:48,49;calonfp
2023,107,14;15:54,49&calonfp/calon
2023,107,14;15:54,49&calonfp/sy=go fivpt &
2023,107,14;15:54,49&calonfp/!+ls
2023,107,14;15:54,49&calonfp/sy=go fivpt &
2023,107,14;15:54,49&calon/"turn cal on"
2023,107,14;15:54,49&calon/"sy=ssh -l oper fs3rtw /usr2/fs/bin/inject_snap -w calon &
2023,107,14;15:54,49&calon/"sy=ssh -l oper fs3rtw /usr2/fs/bin/inject_snap -w check=-rx &
2023,107,14;15:54,49&calon/sy=python /usr2/oper/bin/ncal.py -o on &
2023,107,14;16:00,68;calofffp
2023,107,14;16:00,68#fivpt#tsys 324.720 9.285 40,295 0.4653
2023,107,14;16:06,90#fivpt#lat 1 51364. -0.2545 0.131 0.518
2023,107,14;16:13,14#fivpt#lat 2 51371. -0.1897 -0.301 0.481
2023,107,14;16:19,37#fivpt#lat 3 51377. -0.1249 -0.068 0.486
2023,107,14;16:25,59#fivpt#lat 4 51383. -0.0601 4.782 0.944
2023,107,14;16:31,83#fivpt#lat 5 51389. 0.0047 13.495 1.105
2023,107,14;16:38,06#fivpt#lat 6 51396. 0.0695 8.042 1.868
2023,107,14;16:44,29#fivpt#lat 7 51402. 0.1343 -0.184 0.448
2023,107,14;16:50,50#fivpt#lat 8 51408. 0.1991 -0.420 0.573
2023,107,14;16:56,74#fivpt#lat 9 51414. 0.2639 -0.688 0.707
2023,107,14;16:56,74#fivpt#latfit 0.01544 0.1223 14,3875 -0.4502 -0.0145 5
2023,107,14;16:56,74#fivpt#laterr 0.00174 0.0042 0.4128 0.1768 0.0083 0.3875
2023,107,14;17:02,96#fivpt#lon 1 51420. -0.2610 -0.145 0.486
2023,107,14;17:09,23#fivpt#lon 2 51427. -0.1954 0.488 0.357
2023,107,14;17:15,46#fivpt#lon 3 51433. -0.1297 -0.048 0.110
2023,107,14;17:21,68#fivpt#lon 4 51439. -0.0640 7.081 1.818
2023,107,14;17:27,89#fivpt#lon 5 51445. 0.0016 13.124 0.551
2023,107,14;17:34,13#fivpt#lon 6 51452. 0.0673 6.138 2.490
2023,107,14;17:40,40#fivpt#lon 7 51458. 0.1330 -0.077 0.419
2023,107,14;17:46,66#fivpt#lon 8 51464. 0.1986 0.139 0.600
2023,107,14;17:52,87#fivpt#lon 9 51470. 0.2643 0.220 0.614
2023,107,14;17:52,87#fivpt#lonfit -0.00165 0.1252 13,4354 -0.0806 0.0022 5
2023,107,14;17:52,87#fivpt#lonerr 0.00311 0.0072 0.6568 0.2874 0.0135 0.6265
2023,107,14;17:52,87#fivpt#perform 0.646 550.2 0.644 15.975
2023,107,14;17:52,87#fivpt#offset 325.5681 9.1794 -0.00165 0.01544 1 1
2023,107,14;17:59,08#fivpt#lat 1 51477. -0.2438 1.137 0.350
2023,107,14;18:05,31#fivpt#lat 2 51483. -0.1790 0.472 0.612
2023,107,14;18:11,53#fivpt#lat 3 51489. -0.1142 1.457 0.361
2023,107,14;18:17,75#fivpt#lat 4 51495. -0.0494 7.907 1.763
2023,107,14;18:23,97#fivpt#lat 5 51501. 0.0154 13.316 0.827
2023,107,14;18:30,20#fivpt#lat 6 51508. 0.0803 4.084 0.827
2023,107,14;18:36,44#fivpt#lat 7 51514. 0.1451 -0.291 0.570
2023,107,14;18:42,66#fivpt#lat 8 51520. 0.2099 -0.360 0.525
2023,107,14;18:48,90#fivpt#lat 9 51526. 0.2747 -0.744 0.446
2023,107,14;18:48,90#fivpt#latfit 0.00405 0.1172 13,5436 0.1138 -0.0344 4
2023,107,14;18:48,90#fivpt#laterr 0.00105 0.0025 0.2414 0.1001 0.0048 0.2231
2023,107,14;18:55,13#fivpt#lon 1 51533. -0.2642 0.058 0.491
2023,107,14;19:01,35#fivpt#lon 2 51539. -0.1986 1.038 0.350
2023,107,14;19:07,59#fivpt#lon 3 51545. -0.1329 0.942 0.479
2023,107,14;19:13,81#fivpt#lon 4 51551. -0.0673 6.464 1.457
2023,107,14;19:20,07#fivpt#lon 5 51558. -0.0017 13.285 0.201
2023,107,14;19:26,30#fivpt#lon 6 51564. 0.0640 7.110 1.423
2023,107,14;19:32,54#fivpt#lon 7 51570. 0.1296 0.957 0.388
2023,107,14;19:38,77#fivpt#lon 8 51576. 0.1952 0.505 0.522
2023,107,14;19:45,01#fivpt#lon 9 51582. 0.2609 0.491 0.513
2023,107,14;19:45,01#fivpt#lonfit 0.00058 0.1267 12,9197 0.4393 -0.0003 3
2023,107,14;19:45,01#fivpt#lonerr 0.00201 0.0047 0.4043 0.1785 0.0084 0.3869
2023,107,14;19:47,26#fivpt#perform 0.621 572.2 0.619 15.362
2023,107,14;19:47,26#fivpt#offset 325.8820 9.0075 0.00058 0.00405 1 1
2023,107,14;19:47,26#fivpt#xoffset 325.8820 9.0075 0.00058 0.00405 0.00198 0.00105 1 1 ia cygnusa

```

Measure Tsys off source to calibrate scale

Calibrate both axis

Gaussian fit + offset + slope Opt.: Repeat if not well

Leave telescope „peaked“ on source

Page65

How to monitor

Automate

log=pointing
 proc=r41097wz
 setupsx
 proc=point
 cygnusa
 initp
 ifman
 fivept
 onoff

Define log file
 Set procedure with B
 Setup BBC, IF, ... se
 Define pointing proce
 Point to source
 Init fivept
 Local command to sw
Start fivept □ offsets
Start onoff □ SEFDs

```

2023,107,14:15:48,26:#fivept#source cygnusa 195928.4 +404402 2000.0 2023,107,14:15:48
2023,107,14:15:48,26:#fivept#site WETTZELL -12,8772 49,1450 20.00 xxxx 0 1.00 0.00
2023,107,14:15:48,26:#fivept#azel 2 9 0,50 5 ia 20.8 0.1256 183.5
2023,107,14:15:48,26:#fivept#origin 0.0000 0.0000 0.0016 0.0047 0.0000 0.0000
2023,107,14:15:48,30;calofffp
2023,107,14:15:48,30&calofffp/caloffp
2023,107,14:15:48,30&calofffp/sy=go fivept &
2023,107,14:15:48,30&calofffp/!+ls
2023,107,14:15:48,30&calofffp/sy=go fivept &
2023,107,14:15:48,49;calonfp
2023,107,14:15:48,49&calonfp/calon
2023,107,14:15:48,49&calonfp/sy=go fivept &
2023,107,14:15:48,49&calonfp/!+ls
2023,107,14:15:48,49&calonfp/sy=go fivept &
2023,107,14:15:48,49&calon/"turn cal on"
2023,107,14:15:48,49&calon/"sy=ssh -l oper fs3rtw /usr2/fs/bin/inject_snap -w calon &
2023,107,14:15:48,49&calon/"sy=ssh -l oper fs3rtw /usr2/fs/bin/inject_snap -w check=-rx &
2023,107,14:15:48,49&calon/sy=python /usr2/oper/bin/ncal.py -o on &
2023,107,14:16:00,68;calofffp
2023,107,14:16:00,68#fivept#tsys 324.720 9.285 40,295 0.4653
2023,107,14:16:06,90#fivept#lat 1 51364. -0.2545 0.131 0.518
2023,107,14:16:13,14#fivept#lat 2 51371. -0.1897 -0.301 0.481
2023,107,14:16:19,37#fivept#lat 3 51377. -0.1249 -0.068 0.486
2023,107,14:16:25,59#fivept#lat 4 51383. -0.0601 4.782 0.944
2023,107,14:16:31,83#fivept#lat 5 51389. 0.0047 13.495 1.105
2023,107,14:16:38,06#fivept#lat 6 51396. 0.0695 8.042 1.868
2023,107,14:16:44,29#fivept#lat 7 51402. 0.1343 -0.184 0.448
2023,107,14:16:50,50#fivept#lat 8 51408. 0.1991 -0.420 0.573
2023,107,14:16:56,74#fivept#lat 9 51414. 0.2639 -0.688 0.707
2023,107,14:16:56,74#fivept#latfit 0.01544 0.1223 14,3875 -0.4502 -0.0145 5
2023,107,14:16:56,74#fivept#laterr 0.00174 0.0042 0.4128 0.1768 0.0083 0.3875
2023,107,14:17:02,96#fivept#lon 1 51420. -0.2610 -0.145 0.486
2023,107,14:17:09,23#fivept#lon 2 51427. -0.1954 0.488 0.357
2023,107,14:17:15,46#fivept#lon 3 51433. -0.1297 -0.048 0.110
2023,107,14:17:21,68#fivept#lon 4 51439. -0.0640 7.081 1.818
2023,107,14:17:27,89#fivept#lon 5 51445. 0.0016 13.124 0.551
2023,107,14:17:34,13#fivept#lon 6 51452. 0.0673 6.138 2.490
2023,107,14:17:40,40#fivept#lon 7 51458. 0.1330 -0.077 0.419
2023,107,14:17:46,66#fivept#lon 8 51464. 0.1986 0.139 0.600
2023,107,14:17:52,87#fivept#lon 9 51470. 0.2643 0.220 0.614
2023,107,14:17:52,87#fivept#lonfit -0.00165 0.1252 13,4354 -0.0806 0.0022 5
2023,107,14:17:52,87#fivept#lonerr 0.00311 0.0072 0.6568 0.2874 0.0135 0.6265
2023,107,14:17:52,87#fivept#perform 0.646 550.2 0.644 15.975
2023,107,14:17:52,87#fivept#offset 325.5681 9.1794 -0.00165 0.01544 1 1
2023,107,14:17:59,08#fivept#lat 1 51477. -0.2438 1.137 0.350
2023,107,14:18:05,31#fivept#lat 2 51483. -0.1790 0.472 0.612
2023,107,14:18:11,53#fivept#lat 3 51489. -0.1142 1.457 0.361
2023,107,14:18:17,75#fivept#lat 4 51495. -0.0494 7.907 1.763
2023,107,14:18:23,97#fivept#lat 5 51501. 0.0154 13.316 0.827
2023,107,14:18:23,97#fivept#lon 6 51502. 0.0017 1.004 0.807

```

2023,107,14:18:55,13#fivept#lon	1	51533.	-0.2642	0.058	0.491
2023,107,14:19:01,35#fivept#lon	2	51539.	-0.1986	1.038	0.350
2023,107,14:19:07,59#fivept#lon	3	51545.	-0.1329	0.942	0.479
2023,107,14:19:13,81#fivept#lon	4	51551.	-0.0673	6.464	1.457
2023,107,14:19:20,07#fivept#lon	5	51558.	-0.0017	13.285	0.201
2023,107,14:19:26,30#fivept#lon	6	51564.	0.0640	7.110	1.423
2023,107,14:19:32,54#fivept#lon	7	51570.	0.1296	0.957	0.388
2023,107,14:19:38,77#fivept#lon	8	51576.	0.1952	0.505	0.522
2023,107,14:19:45,01#fivept#lon	9	51582.	0.2609	0.491	0.513
2023,107,14:19:45,01#fivept#lonfit		0.691	12,9197	0.4393	-0.003 3
2023,107,14:19:45,01#fivept#lonerr		0.00201	0.0047	0.4043	0.1785 0.084 0.3869
2023,107,14:19:45,01#fivept#perform		572.2	0.619	15.362	
2023,107,14:19:47,26#fivept#offset		325.8820	9.0075	0.00058	0.00405 1 1
2023,107,14:19:47,26#fivept#xoffset		325.8820	9.0075	0.00058	0.00405 0.00198 0.00105 1 1 ia cygnusa

Offsets corrected for the cosine of second coordinate:
cross-elevation and elevation

How to monitor system quality?

Automated Pointing Model

log=pointing
 proc=r41097wz
 setupsx
 proc=point
 cygnusa
 initp
 ifman
 fivept
 onoff

Define log file
Set procedure with BBC, IF, ... settings
Setup BBC, IF, ... settings
Define pointing procedure
Point to source
Init fivept
Local command to switch AGC off
Start fivept offsets
Start onoff SEFDs

Power on source (#ONSO)
 Power on source with noise diode on (#ONSC)
 Power off source with noise diode on (#OFFC)
 Power off source with noise diode off (#OFFS)
 Power off source with no signal for „zero“ (#ZERO)
Result:

		source	Az	E1	De	I	P	Center	Comp	Tsys	SEFD	Tcal(j)	Tcal(r)
2023.107.14:20:40.51#onoff#			326.1	8.9	11	1	r	8208.99	0.9474	49.97	735.0	305.954	0.02
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	81	2	r	8928.99	0.9596	44.57	741.7	346.158	0.02
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	1u	1	r	8216.99	0.9452	52.07	742.9	296.768	0.02
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	2u	1	r	8256.99	0.9409	63.27	861.9	283.311	0.02
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	3u	1	r	8356.99	0.9531	45.06	702.7	324.382	0.02
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	4u	1	r	8516.99	0.9499	44.92	673.3	311.766	0.02
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	5u	2	r	8736.99	0.9568	52.05	833.2	332.974	0.02
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	6u	2	r	8856.99	0.9619	40.85	732.8	373.038	0.02
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	7u	2	r	8896.99	0.9592	43.07	739.3	357.040	0.02
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	8u	2	r	8936.99	0.9606	47.81	788.7	343.127	0.02
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	9u	3	r	2229.99	0.6986	63.06	1722.8	584.645	0.03
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	au	3	r	2249.99	0.6780	66.75	1680.2	538.700	0.03
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	bu	3	r	2269.99	0.6684	70.32	1694.9	515.783	0.03
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	cu	3	r	2299.99	0.6602	76.89	1748.4	486.595	0.03
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	du	4	r	2349.99	0.6929	64.34	1573.3	523.284	0.03
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	eu	4	r	2369.99	0.6931	61.49	1481.0	515.371	0.03
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	ia	1	r	8341.00	1.0557	40.44	576.6	296.611	0.02
2023.107.14:20:40.51#onoff#VAL	cygnusa		326.1	8.9	ib	2	r	8848.00	0.7727	49.08	596.5	252.805	0.01
2023.107.14:20:40.51#onoff#	cygnusa		326.1	8.9	ic	3	r	2281.00	5.0987	388.5	3423.4	188.538	0.01
		source	Az	E1	De	I	P	Center	Comp	Tsys	SEFD	Tcal(j)	Tcal(r)

**Process „fivept“
and „onoff“**

How to monitor system quality?

Automated Pointing Model



Video

System Status Monitor									
WETZELL		2023.107.14:14:25		UT	TEMP	12.2	cygnusa		SLEWING
MODE	RATE			14:18:52	NEXT	HUMID	52.0	RA	19h 59m 28.40s
				SCHED=	none	LOG=	station	PRES	948.4 (2000)
		TSYS:		IFA	IFB	IFC	IFD	CABLE	0.006372
				0	0	0	0	AZ	325.1453
								EL	9.4158
NO CHECK rx									
Wind: 23.04 DIR: 36									

Mark 5 Remaining Capacity				
VSN	Time	GB	%	Check UT
A				100% (Volume)
B				100% (Volume)

Select Quality Monitoring: System Temperatures	
System Temperatures	
Tsys	0.00 (IFA) 0.00 (IFB)
	0.00 (IFC) 0.00 (IFD)
BBC	Freq Ts-U Ts-L
01	132.99
02	172.99
03	272.99
04	432.99
05	652.99
06	772.99
07	812.99
08	852.99
09	205.99
10	225.99
11	245.99
12	275.99
13	325.99
14	345.99
15	0.00
16	0.00



Antenna Monitoring		
RTW ([2023] 107.14:14:25:109 (Offset: 0 msec))		
Azimuth	Source: Az El Pos	Elevation
59.9465	Actual Pos.	25.0048
	Pos. Graph	
60.0000	Commanded Pos.	25.0000
325.1446	NASA FS Pos.	9.4163
0.0016	Com. Pos. Offset	0.0047
PRESET		PRESET
Status messages		
[Azimuth]	[General]	[Elevation]
Preset	ACU type: RTW	Preset
Stow pin retracted	Reduced internal limits che	Stow pin retracted
	Green mode inactive	
	Error messages	

Station Monitoring		
Dewar		
Time:	2023.107.14:13:46	
(2023-04-17)		
70K:	74.15K	
20K:	21.70K	
Pressure:	1.2710^-6 mbar	
Amb. Temp.:	16.68°C	

Master Clock Offset		
Time:	-0.6	
EFOS39:	(= - 0.6) usec	
TAC2:	usec	

Local Frequency		
No active session!		

Pointing (fivept)		
Time:	2023.107.08:23:34	
Source:	cygnusa	
Position:	271 deg / 58 deg	
Az. Offset:	0.02565deg	
Az. Offset:	0.01305deg	
Status:	OK	

Log	
(Load separately)	
Error	<pre>2023.107.12:32:03:03?ERROR q1=307 WARNING: Source structure correction greater than 20% for detector 11. 2023.107.12:32:34:35?ERROR nf=7 WARNING: Source structure correction greater than 20% for detector 11. 2023.107.12:32:45:52?ERROR q1=307 WARNING: Source structure correction greater than 20% for detector 11. 2023.107.12:33:16:46?ERROR nf=7 WARNING: Source structure correction greater than 20% for detector 11. 2023.107.12:41:18:58?ERROR q1=307 WARNING: Source structure correction greater than 20% for detector 11. 2023.107.12:41:50:05?ERROR nf=7 WARNING: Source structure correction greater than 20% for detector 11.</pre>
Log	<pre>2023.107.14:13:39:45#onoff#VAL cygnusa 324.9 9.5 eu 4 r 2369.99 0.7264 64.27 1436.9 478.438 0.03 2023.107.14:13:39:45#onoff#VAL cygnusa 324.9 9.5 ia 1 r 8341.00 1.0494 39.11 562.8 299.305 0.02 2023.107.14:13:39:45#onoff#VAL cygnusa 324.9 9.5 ib 2 r 8848.00 0.8646 50.90 715.3 292.280 0.02 2023.107.14:13:39:45#onoff#VAL cygnusa 324.9 9.5 ic 3 r 2281.00 0.7447 68.60 2004.2 625.191 0.04 2023.107.14:13:39:45#onoff#source Az El De IP Center Comp Tsys SEFD Tcal(j) Tcal(r) 2023.107.14:13:52:74#antenna=safepos 2023.107.14:13:52:74#antcn#ACU move to standard stow position 2023.107.14:13:52:76#antenna ACK 2023.107.14:13:58:63#flagr=flagr#antenna,off-source</pre>


xsamba.wtz(neidh)

```
fsrtw:/usr2/oper/:> oprin
```

How to monitor system quality?

Schedule an Automated Pointing Model with „acquire“


Setup:

Configure „ctlpo.ctl“

```
3C84      031948.16 +413042.1 2000 PREP   -1 10  0  0 POSTP   -2
* 3C123    043704.17 +294015.1 2000 PREP   -1 10  5  0 POSTP   -2
* 0521M365  052257.98 -362730.9 2000 PREP   -1 10  5  0 POSTP   -2
TAURUSA   053432.   +220058  2000 PREP   -1 10  5  0 POSTP   -2
* ORIONA    053516.  -052322.  2000 PREP   -1 10  5  0 POSTP   -2
* 3C147     054236.14 +495107.2 2000 PREP   -1 10  5  0 POSTP   -2
* 0552P398  055530.8  +394849.  2000 PREP   -1 10  0  0 POSTP   -2
* 3C161     062710.10 -055304.8 2000 PREP   -1 10  5  0 POSTP   -2
* OJ287     085448.9  +200631.  2000 PREP   -1 10  0  0 POSTP   -2
* 3C218     091805.7  -120544.  2000 PREP   -1 10  5  0 POSTP   -2
* 4c39d25   092703.0  +390221.  2000 PREP   -1 10  0  0 POSTP   -2
* 3C273B    122906.70 +020308.6 2000 PREP   -1 10  0  0 POSTP   -2
* VIRGOA    123049.42 +122328.0 2000 PREP   -1 10  5  0 POSTP   -2
* 3C279    125611.17 -054721.5 2000 PREP   -1 10  0  0 POSTP   -2
* 3C286    133108.29 +303033.0 2000 PREP   -1 10  5  0 POSTP   -2
* 3C295    141120.65 +521209.1 2000 PREP   -1 10  5  0 POSTP   -2
* 3C345    164258.81 +394837.0 2000 PREP   -1 10  0  0 POSTP   -2
* 3C348    165108.2  +045933.  2000 PREP   -1 10  5  0 POSTP   -2
* 3C353    172028.2  -005848.  2000 PREP   -1 10  5  0 POSTP   -2
* 3C380    182931.72 +484447.0 2000 PREP   -1 10  5  0 POSTP   -2
* 3C391    184923.4  -005529.  2000 PREP   -1 10  5  0 POSTP   -2
* 1921M293  192451.06 -291430.1 2000 PREP   -1 10  0  0 POSTP   -2
CYGNUSA   195928.4  +404402.  2000 PREP   -1 10  5  0 POSTP   -2
* 2134P004  213638.59 +004154.2 2000 PREP   -1 10  0  0 POSTP   -2
* 3C454D3   225357.75 +160853.6 2000 PREP   -1 10  0  0 POSTP   -2
CASA      232324.8  +584859.  2000 PREP   -1 10  5  0 POSTP   -2
* SUN      000000.  000000  2000 PRESUN  -1 10  5  0 POSTSUN  -1
* MOON     000000.  000000  2000 PREMOON -1 10  5  0 POSTMOON -2
```


Process „acquire“:

```
proc=r41097wz
setupsx
proc=point
initp
acquire
```




How to monitor system quality?

Schedule an Automated Pointing Model with „acquire“



How to monitor system quality?

Schedule an Automated Pointing Model with „acquire“



TOW2025 - Maintenance Workshops

FS Operations

Thank you ...